

### Объём заливаемого масла.

<b>NMRV</b>	<b>030</b>	<b>040</b>	<b>050</b>	<b>063</b>	<b>075</b>	<b>090</b>	<b>105</b>	<b>110</b>	<b>130</b>	<b>150</b>
<b>B3</b>	0.04	0.08	0.15	0.3	0.55	1.0	1.6	3	4.5	7
<b>B8</b>								2.2	3.3	5.1
<b>B6-B7</b>								2.5	3.5	5.4
<b>V5</b>								3	4.5	7
<b>V6</b>								2.2	3.3	5.1